

TYPICAL CONFIGURATIONS V5
Three Wire Start/Stop Control, Remote Reset with DC Brake.

S/W version 2.1

Created: **B.Sheridan**
Position: **Technical Director**
Date: **14/07/04**

Reviewed: **M. Duncan**
Position: **Sales and Marketing
Director**
Date: **14/07/04**

TYPICAL CONFIGURATIONS V5

Three Wire Start/Stop Control, Remote Reset with DC Brake.

1.- Parameter Configuration.

CODE	DESCRIPTION	DISPLAY	VALUE (DEFAULT)
NAMEPLATE			
G2.1	Soft Starter Current	I Starter	(Rated nameplate current of soft starter)
G2.2	Motor Current	I Motor	(Auto dependant on V5 model) Adjust to motor nameplate FLC
G2.3	Motor Voltage	V Motor	(380V/440V)
G2.4	Motor Power	P Motor	(11) Adjust to motor nameplate Power
G2.5	Motor Cosinus Phi	Cos Phi M	(85%) Adjust to motor nameplate Power Factor
G2.6	Supply Frequency	Freq	(50Hz)
PROTECTIONS			
G3.1	Phase Sequence	Phase Sequen	(L1, L2, L3 Seq)
G3.2	Overload Motor Current	Overload	(Auto dependant on V5 model) Adjust to motor nameplate FLC
G3.3	Overload Curve	O/load Curve	(5)
G3.4	Starting Overload Factor	Oload Factor	(100%)
G3.5	Motor PTC	Motor PTC	(No)
ACCELERATION			
G4.1	Start Delay	Str Delay	(0)
G4.2	Torque Pulse	Puls Torq	(50%)
G4.3	Torque Pulse Time	Pulse Tq T	(Off)
G4.4	Initial Torque	Init Torque	(35%). Adjust to suit load requirements. Pumps and low inertia loads typically 40%~45%. Higher inertia loads may be between 45% ~80%
G4.5	Initial Torque Time	Init Tq T	(1s)
G4.6	Acceleration Time	Acel Time	(6s) Adjust to suit application requirements
G4.7	Current Limit	I Limit	(3 * In of V5 model). Set to load requirements. Typically between 300% and 450% of motor FLC
DECELERATION			
G5.1	Freewheel Stop	Frewel Stp	(Yes). Set to No for ramped stop
G5.2	Deceleration time	Decl Time	(12). Set to load requirements.
INPUTS			
G6.1	Control Mode	Oper Mode	(0). Set to 2 for control from digital inputs
G6.2	Local Reset	Local Reset	(Y)
G6.3	Digital Input 1	D Input1 Sel	(0). Set to 1 for start
G6.4	Digital Input 2	D Input2 Sel	(0). Set to 2 for stop
G6.5	Digital Input 3	D Input3 Sel	(0). Set to 5 for reset
G6.6	Digital Input 4	D input4 Sel	(0). Set to 8 for DC Brake
DC BRAKE			
G13.1	DC Brake Selection	DC Brak Sel	(No). Set to Yes to enable DC Brake
G13.2	DC Current Injection	DC Brak I	(50%). Adjust to suit stopping or hold requirements.
G13.3	DC Brake Time	DC Time	(0s). Adjust to suit stopping or hold requirements
G13.4	Enable external DC Brake	External B	(N).

2.- Control terminal connections.

Terminal 10	: Common
Terminal 11	: Programmable digital input 1 (set to Mode 01 = Start)
Terminal 12	: Programmable digital input 2 (set to Mode 02 = Stop)
Terminal 13	: Programmable digital input 3 (set to Mode 05 = Reset)
Terminal 14	: Programmable digital input 4 (set to Mode 08 = DC Brake)

